

# Important Instructions



Covers all EKB Models  
From: 208 / 240 Volt  
From: 2850 Watt to 5000 Watt



Fig 1.1

**⚠ DANGER ⚠**

**ELECTRIC SHOCK OR FIRE HAZARD**

Read all wire sizing, voltage requirements and safety data to avoid property damage and personal injury.

EKB Series  
Electric Unit Heater  
For Garage and Shop



**WARNING**



**Read Carefully** - These instructions are written in an effort to prevent potential difficulties that might arise during installation. Studying the instructions first may save you considerable time and money later. Observing the following procedures will keep installation time to a minimum. **Save these instructions for future use.**

## IMPORTANT INSTRUCTIONS

**When using electrical heating appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:**

1. Read all instructions before wiring or using this heater.
2. Heaters outlet grill is very hot when in use. To avoid burns, do not touch hot surfaces with bare skin. Keep combustible materials, including furniture, pillows, bedding, papers, clothes, curtains, and boxes at least three feet (.9 m) from the front of the heater and keep them away from the sides and rear.
3. Do not use outdoors.
4. Heater is not intended for use in bathrooms, laundry areas or similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
5. Do not insert or allow foreign objects to enter any inlet or outlet openings as this may cause an electric shock, fire, or damage to the heater.
6. To prevent a possible of fire, do not block air intakes or exhaust in any manner.
7. Heater has hot surfaces. Internal thermostat and limiting parts will arcing or create sparks inside. Do not use this heater in areas where gasoline, paint, or flammable liquids or gases are used or stored.
8. Use this heater only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock, explosion or injury to people and or property.
9. If heater shows signs of overheating immediately turn the circuit breaker off to the heater. Remove and inspect for any objects on or adjacent to the heater that may cause the high temperatures. Have a professional inspect the internals until the reason is clear why the heater is overheating. Do not reinstall until it has been professionally serviced.
10. Do not operate heater after it malfunctions. Disconnect heater at service panel and have heater inspected by a reputable electrician before reusing. To disconnect heater, turn controls to off position, and turn off power to heater circuit at main electrical panel or operate internal disconnect switch to off if provided.
11. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended too.

**SAVE THESE INSTRUCTIONS**

# General Operation

## EKB Unit Heater

10 1/2 in./27.6 cm  
Pivot to top of bracket




Fig 2.1

Heater case size  
w/o bracket  
Height: 13 5/8 in. / 34.6 cm  
Width: 10 3/8 in. / 26.35 cm  
Depth: 9 3/4 in. / 24.76 cm

Maximum Outside Dims  
W/bracket and stat  
Height: 18 3/4 in. / 47.62 cm  
Width: 11 3/8 in. / 28.90 cm  
Depth: 10 5/8 in. / 26.98 cm

## Bracket Information

Hole Sizes  
\* 1/2" in./1.27 cm 3 Holes  
+ 1/4 in. / .63 cm 4 Holes




Fig 2.2

### General information and Guidelines:

Heater is intended for garage shop and studio heating of large areas from 400 to 1250 square feet depending on your location and climate. Colder climates require more heat or wattage per square foot than warmer climates. In some cases it may be necessary to use multiple units to obtain ideal temperature control. If more than one unit is required. Arrange the heaters so they create a circular air pattern around the outside of the room, or across the coldest walls.

Insulation will aid in retaining heat provided by your new heating system, and will reduce energy costs associated with heating.

The thermostat in the EKB has a range from 40 to 90 degrees with a freeze protection setting of approximately 50 degrees. Freeze protection temperature is approximate and should be verified with the digital thermometer if it is important that freeze protection is critical or a potential freeze could cause damage. The heater is equipped with a bracket that allows it to be mounted to either the ceiling or the wall. The heater can then be tilted 25 degrees to direct heated air towards the floor. Never point at the ceiling, toward other appliances or objects that obstruct the airflow, or toward objects that could be damaged by excessive heat or have the potential to catch fire due to prolonged exposure to heat. Following these simple guidelines will have provide you with a comfortable safe heating system for years to come.

### Heater inner workings:

The EKB cast aluminum motor incorporates a large oil reservoir that is maintenance free and recirculates the oil across the shaft at a rate of 5 drops per minute. The motor is Thermally protected for safety. The 80/20 Ni-Chrome elements allow for quick heating and cooling type leaving all the heat in the room by time the fan stops. A self-holding over-temp limit is provided on each element as well as one main self holding limit located between the elements for total shut off. If the total heater shut off limit trips the heater is disabled until the power to the heater is shut off for 10 minutes at which point it will reset. There is no fan delay on start up or shut off so no special complicated feed wiring is required for remote thermostat connections. (i.e. switch loops circuits).

### Operation:

The EKB heater requires mounting in a clear, open-air location for optimal performance.

Heater should be installed in a location that is clear and will remain of storage items. The heat outlet of the unit should be able to push warmed air to the far side of the room. Ample space should be left behind the heater to allow air to be drawn in through the back of the unit. Clearance recommendations within these instructions are the minimum, providing more space will result in improved airflow and safer operation.

### Maintenance instructions:

Turn off circuit breaker to heater.

Motors are maintenance free and do not need to be oiled. Heater will need to be blown out and cleaned every year, in order to be kept free of all dust, dirt and fibers that may accumulate. Use compressed air to free up any particles that may have entered the heater. Fan blades should be clean and able to move freely. Wipe both the front and rear grills and continue to keep clear all debris and wiped clean with a soft towel.



# Mounting Instructions





Fig 3.1



After bracket is mounted, place washers on bolts and then in heater sides. Drop onto bracket slots placing lock washer between heater and bracket and washer between bracket and bolt. Adjust to the preferred angle and tighten bolts to 30 ft. lbs. of torque minimum.




Fig 3.4




Fig 3.2




Fig 3.5

Heater may be mounted to the wall or ceiling. For best performance and satisfactory results the heater **should not** be mounted over 10 feet high off the floor. **Minimum distance off the floor is 6 ft.** per UL standards 2021.

For wall installation the bracket must have the hook end pointing up so if the heater were to loosen over time it would not fall out. See Fig 3.3

Wall stud and ceiling joists are typically wider than our mounting bracket which is 11 inches wide. The heater weighs 14 lbs. and should be mounted onto at least one stud to be properly supported.

Your fasteners penetrating a stud is critical to supporting the weight. A gypsum wall board fastener is not strong enough. But if your ideal location has no solid backing. You can fasten with large screw fasteners a 2 x 6 across the studs or ceiling joists and attach the heater then to the 2 x 6. This works for ceiling or wall mounting. Attach with appropriate lag bolts with proper depth for the 14 lbs. Install hex fasteners into both sides of heater with washer on the outside of the bracket and star washer between the heater and bracket.

## Minimum clearances from walls and ceiling

**6 inches / 15.24 cm to the side**

**5 inches / 12.7 cm from the back**

**2 inches / 5.08 cm from ceiling**

**Never point heater at ceiling**

**Maintain clearance of at least 3 ft. in front of heat outlet**

## Heater Location Instructions:

Arrange the heater so the hot discharge air is:

1. Free of interference from any items that could block or disrupt the airflow reaching the farthest point of the area being heated.
2. Direct the airflow along the coldest part of the garage area without blowing the heat directly at the wall or warming the items in any way. Typically a distance of 3 to 4 feet is away from walls or cabinets is acceptable.
3. Do not blow directly on stationary people in the room or work areas.
4. Smaller rooms will be comfortably heated with one unit. Larger rooms may require multiple heaters. Moves the air in a circular, wall wiping pattern around the room. This configuration aids in pre-heating the incoming air of the next heater and will raise the room temperature faster. See Fig 3.4 and 3.5

## Thermostat:

The inbuilt thermostat has a range of 40 to 90 degrees F and when set will keep the room at a comfortable temperature. We recommend experimenting with settings to determine ideal room temperature while occupied and unoccupied. Once those ideals are identified, mark the settings on the label with a felt tip marker.

If a remote line voltage thermostat is used it should be rated for higher than the amp load of the heater connected. Locate the thermostat 5 ft. (1.5 m) above the floor on an interior wall away from cold drafts, cold steel posts, outside walls, hot water pipes, hot lights and away from the discharge air stream of the heater.

**SAVE THESE INSTRUCTIONS**

# Installation

**CAUTION!**  
Turn off all electrical power to install wiring

**⚠ DANGER ⚠**

**ELECTRIC SHOCK OR FIRE HAZARD**

Read all wire sizing, voltage requirements and safety data to avoid property damage and personal injury.

## Rating Label on back of heater

KING ELECTRICAL MFG.  
9131 10TH AVE SO.  
SEATTLE WA. 98108

**ELECTRIC UNIT HEATER**  
Tested to UL2021

<b>MODEL: EKB2450</b> <b>WATTS: 5000/4000</b> <b>VOLTS: 240 / 208</b> <b>AMPS: 20.8/19.2</b>	<b>CAUTION: RISK OF ELECTRICAL SHOCK.</b> <b>DANGER: RISQUE D'ELECTROCUTION</b>
---	--

Do not install heater closer than:  
 Ne Pas installer cet aérotherme a moins de  
 from floor 6" (1.5M) Du plancher  
 side wall 6" (15cm) Du mur  
 from ceiling 2" (5 cm) Du plafond  
 When heater is installed 2" in.  
 from ceiling do not point at ceiling.  
 Ne pas pointer au plafond

Disconnect power before servicing. Do not operate heater with parts removed, no user serviceable parts  
 Use only on 30amp branch circuit. Not to be used in explosive environments. Debrancher pour service. Ne pas utiliser cet aérotherme lorsque les couvercles sont ouvert. Utiliser seulement avec circuit de 30 amperes. Ne pas utiliser dans les environnements explosifs.

08/16/12

Fig 4.0

## Wire and Breaker sizing

The wire and breaker sizing chart will give a general rule of installation size. If you have long distance wire runs, larger size wire is required due to voltage drops. Consult an electrician if you are not knowledgeable about wiring codes.

### Wiring Branch Circuit Connection

1. Connect heater only to the voltage, amperage and frequency specified on the nameplate.
2. Wiring procedures and connections shall be in accordance with all National and local codes having jurisdiction.
3. Removing the two screws on the bottom of the heater will allow you to gain access to the wiring compartment.
4. A knock of 1/2 inch (12.7 mm) conduit size (7/8 inch) is provided in the back of the heater for power to enter. Provide proper conduit connectors for your flexible connections.
5. Wires will be placed in the terminal block lugs labeled L1 and L2 and tightened to 35 lbs. of torque. Lugs are approved for copper or aluminum conductors from # 14 to #2 AWG. Minimum 600 volt 60 degree C wire is required. Copper wire is recommended. Fig. 4.2
6. Attach ground to the green wire with a wire nut.
7. Assemble all covers on electrical and apply power. Test unit by turning thermostat up past room temperature. You will see a puff of smoke as the elements are energized and the fan turns on. This is a normal burn off of manufacturing lubricants and will dissipate in 5 minutes.
8. Heater will continue to run until the room temperature you set is reached and then turn itself off until the temperature drops again.
9. **CAUTION - High temperature.** Risk of fire, keep electrical cords, drapery, furnishings, and other combustibles at least 3 feet (0.9 m) from the front of the heater as well as away from the side and rear. To reduce the risk of fire, do not store or use gasoline or other flammable vapors and liquids in the vicinity of the heater.

### Other manufacturing options to add to EKB

- Pilot light- Add Suffix **-P**
- Circuit breaker- Add Suffix **-CB**
- Disconnect switch -Add Suffix **-DS**
- Add Suffix to end of EKB model number

Model	Volts	Watts	Amps	Wire	Breaker size
EKB2450	240	5000	20	10-2 w/ground	30 Amp 2 pole
EKB2050	208	5000	24	10-2 w/ground	30 Amp 2 pole
EKB2440	240	3850	16	12-2 w/ground	20 Amp 2 pole
EKB2040	208	3750	18	10-2-w/ground	30 Amp 2 pole
EKB2430	240	2850	12	14-2 w/ground	15 Amp 2 pole
EKB2030	208	2850	14	12-2 w/ground	20 Amp 2 pole

Fig 4.1




Fig 4.2

**SAVE THESE INSTRUCTIONS**

